Camera description





Waterproof case

Specially designed for diving, surfing and water sports; waterproof case is suitable for recording up to 10m underwater. Supplied accessories make the case also ideal for use and fixing even out of the water.

- Clean the rubber gasket to prevent accidental water infiltration before close the case
- Do not use underwater if the gasket is worn / damaged
- By closing the camera inside the hermetic case, the audio could suffer significant drops in quality and sound level